



# How to install SkidGuard



Always wear appropriate safety gear, masks, filters and glasses, and always dispose of used materials in a safe and environmentally friendly manner. Check MSDS for appropriate info on safety issues.

## Prepare Surface

1. Grind Surface
2. Prep surface area to be installed with applicable tape and borders, always ensuring that all surfaces are clean and dry.

## Mix it up

3. Shake/mix "Base" material thoroughly. 2 minute minimum
4. Mix small "test" amount, with appropriate levels of catalyst to ensure proper viscosity. See Mixture Ratios
5. Mix thoroughly.

## SkidGuard Mixture Ratios

1 Gallon BASE Material



CATALYST



4 Tablespoons POWDERED



2 Inches PASTE

## Application

6. Load roller with (catalyzed) material by pouring material on surface desired and rolling completely the locations you want the material placed in one direction.
7. "Cross roll" to obtain the finished look. This "raises the nap" to give it a more non-skid texture.)
8. Raise nap to create nonskid surface texture.
9. After all materials have been placed as desired, remove tape or border material while material is still in a plastic state.
10. Protect installed areas from all pedestrian for 6–12 hours, and vehicular traffic for 24–36.

**CAREFUL! Do Not Over-Roll.** As material begins to catalyze, move roller off the surface. Roll material after it begins to harden will cause the material to be pulled off the surface by the roller.

Vanguard ADA Systems • Snohomish, WA • Ph 360-668-5700 • Request a SkidGuard Kit Quote



PEDESTRIAN AREAS



RAMPS



STAIRS